



Apex Ultra Lite® Set Up Instructions

Step 1. Place your Apex Ultra Lite Frame in the center of the set up area. With a partner on the other 10' side of the frame, hold onto the two outer legs and lift frame off the ground slightly for clearance. Take a few steps backward until you have extended the frame a full arms length-approx. 4 feet (Fig. 1.1). To improve the opening and closing action of your Apex frame, you may spray some silicone lubricant on the outer legs. Place the canopy top over the top of the frame (Fig. 1.2)



Fig. 1.1



Fig. 1.2

Step 2. Use the Velcro strips to secure each corner of the top to the frame on corresponding Velcro already attached to the frame (Fig. 2.1). Locate the Velcro tab location in the center of the top (Fig. 2.2). Attach Velcro tabs around a single truss bar (Fig. 2.3). Be sure not to attach Velcro tab around more than one truss bar, as you will rip out the Velcro upon closing the canopy. This will not be covered by warranty. Your Top is now attached to frame.



Fig. 2.1



Fig. 2.2




Fig. 2.3

Step 3. Grab the bottom of the middle frame section where it forms a "V" shape (Fig. 3.1). Lift frame off the ground slightly and slowly walk backward until the frame is fully extended. Take care to avoid pinching your hands or fingers.



Fig. 3.1

Step 4. Prior to locking the leg sliders, partially fold back the canopy at each corner to increase visibility. Next, hold the leg of the frame with one hand and lift the slider (Fig. 4.1). For ease in opening, depress the locking button while pushing the slider up until the slider passes over the locking button (Fig. 4.2). Return folded corner of the canopy to proper position.



Fig. 4.1




Fig. 4.2

Step 5. The adjustable legs offer multiple height levels. To adjust, lift the leg up and pull the inner leg until the button pops into place (Fig. 5.1). Repeat on the other legs. Use stakes or weight bags to secure frame to the ground. Enjoy your new Apex Tent!



Fig. 5.1





Apex Ultra Lite®

Take Down Instructions

Note: The top cover may remain in place for easier subsequent set-ups.

Warning: Before storing your Apex Ultra Lite canopy, be sure the top is not wet or damp. Storing your canopy while it is even slightly damp may cause mildew. Allow your canopy to completely dry before taking it down. If you must take down the canopy, remove the top from the frame by unfastening the Velcro strips, and nuts. Fold up the frame and lay the top down, fully open, as soon as possible and allow to completely dry.

Cleaning: Use water, mild soap and a soft brush to clean any soiled areas. Allow to completely dry.

Step 1. Remove stakes from the ground. Depress the height adjusting button on each leg and reduce the canopy to its shortest position (Fig. 1.1) When completed, each leg will be fully inside the larger outer leg.




Fig 1.1

Step 2. At each corner, partially fold back canopy to where it attaches to Velcro. Next, push in the locking button and pull the slider down slowly until the button pops out above the slider (Fig. 2.1).




Fig. 2.1

Step 3. Grab the top of the middle frame section, on the 10' ends as shown (Fig. 3.1). Lift frame off the ground slightly and slowly walk towards partner as the frame folds in. Keep walking until the frame is almost closed. Next, grab the two outer legs while still holding frame off the ground and push together to fully close the frame (Fig. 3.2) Take care to avoid pinching your hands or fingers.



Fig 3.1



Fig 3.2

Step 4. Place your Apex Ultra Lite canopy inside the carry bag for easy transport and storage (Fig. 4.1 & 4.2).



Fig 4.1



Fig 4.2