



Portable Tripod Stand




fig. 1




fig. #2




fig. #3




fig. #4




fig. #5

Step 1: Lay the Tripod Stand flat on ground (*see fig. #1*).

Step 2: Slide the legs out to the fully extended position by pressing in on the locking button at the top of the unit (*see fig. #2*). The legs are composed of 3 separate sections; ensure that all three legs are fully extended and that the tabs are locked in position

Step 3: Stand the Tripod up on a level, non-slippery surface. Spread the legs of the Tripod apart to create the largest possible base (*see fig. #3*).

Step 4: Locate the lever located on the bottom side of the top of the Tripod, below the assembly piece where the three legs come together (*see fig. #4*). On this piece is a locking mechanism that secures the legs in the spread position. Rotate the mechanism fully to the right (OPEN) to secure legs in place.

Step 5: Locate the rope piece with three branches. Place one of the supporting end cups of the rope piece over the plastic foot on the bottom of a Tripod leg, and repeat for all three legs (*see fig. #5*). This rope piece ensures that the Tripod legs will not slide further away from the center of gravity. The Tripod **SHOULD NOT** be used without the rope piece. If this piece was not included, contact Hammaka at 877-426-6252 for a replacement piece.

Step 6: Hang the Hammaka Hammock Chair from the eye bolt (See Hammock Chair Assembly Instructions).

Step 7: Always test the security of the Hammaka Hammock Chair and Tripod Stand prior to use.

CAUTION! DO NOT JUMP, BOUNCE, OR SWING in the stand. The Hammaka Hammock Chair is not designed as a swing. Maximum weight capacity of the tripod stand is 350 lbs. Do not exceed maximum weight.

